

Inspection Mirror



Micronova Inspection Mirrors are highly polished stainless steel plates with a 360° swivel joint connection that attaches to a threaded STA plastic series or SSU Quick Disconnect stainless steel handle. Operators can safely use the mirror inside process tanks, and around equipment and fixtures to ensure all surfaces have been properly cleaned without introducing a glass mirror into a controlled environment.



- Stainless steel plates are polished to a mirror finish
- 360° swivel joint connection version facilitates use behind and below equipment
- Attaches to either SSU or STA series handles
- Two convenient sizes 4 x 4 in (10 x 10cm) and 6 x 6 in (15 x 15cm)
- 6x6 in mirror with plastic backing option to protect surfaces
- Optional flashlight and mirror cover available
- Options without plastic backing are autoclavable

SPECIFICATIONS

Materials of Construction:

Mirror Plate: Highly electropolished stainless steel
360° Swivel: Polyketone
Mirror Backing: Acetal

Dimensions:

Plate: 6 x 6 in (15 x 15 cm)
4 x 4 in (10 x 10 cm)

Swivel Adapter flat:
2-1/2 in (6 cm)

Swivel adapter extended:
9 in (22.86cm)

Weight: Less than 2 pounds

Manufactured for use in Controlled Environments

- ISO 5 thru 9 Cleanrooms
- ISO 9001 Certified Manufacturing Facility

QDIST-44

Inspection Mirror, 4 x 4 in (10 x 10 cm)

QDIST-66

Inspection Mirror, 6 x 6 in (14 x 14 cm)

QDIST-66P

Inspection Mirror with Plastic Plate,
6 x 6 in (14 x 14 cm),
OAL: 6.5 x 6.5 in
(16.51 x 16.51 cm) with
acetal backing



Micronova Manufacturing, Inc.
3431 W. Lomita Boulevard
Torrance, CA 90505-5010 USA

Tel: 310/784-6990
Fax: 310/784-6980

SalesInfo@micronova-mfg.com
www.micronova-mfg.com