

SlimLine™ Mop Adapter



The Micronova **SlimLine™ Mop Adapters** for cleanrooms are the base unit for a range of Micronova flat head mops including: SnapMop™, PocketMop™, FlatMop™, SlimLine™, and PadMop™. The adapters feature a unique 360° swivel joint which allows an easy glide for cleaning flat surfaces and can be locked at 180° for more controlled cleaning of ceilings, walls and surfaces within hoods and chambers. The mop adapters are available with a stainless steel plate or polypropylene plate. The stainless steel mop frame has a polyketone swivel and handle attachment, the polypropylene includes a polypropylene swivel.

- 360° plastic swivel joints provide easy maneuverability
- 180° locked position for more control
- 304 stainless steel plate is electropolished
- Polypropylene plastic plate is lightweight, yet durable

Use with Micronova mops and hardware

- Compatible with SnapMop, PocketMop, FlatMop, SlimLine, and PadMop series of mop covers
- SlimLine and Slim T bucket systems and wringers
- SSU series stainless steel handles for QDSL, stainless steel steel frame adapters
- STA series plastic handles for QPSL, polypropylene frame adapters and QSSL, stainless steel frame mop adapters.

Manufactured for use in Controlled Environments

- ISO 5 thru 9 Cleanrooms
- ISO 9001 Certified Manufacturing Facility
- Autoclavable
- Good chemical resistance to disinfectants and cleaning solutions



SPECIFICATIONS

Materials of Construction:

	Plate:	Swivel Joint:	Locking Cap:
QD Series:	Stainless steel	Polyketone & Stainless Steel	N/A
QP Series:	Polypropylene	Polypropylene	Polyketone
QP Large:	Acetal	Polyketone	Polyketone
QS Series:	Stainless Steel	Polyketone	Polyketone

Dimensions:

Plates:

QD, QS and QP Series:
 4" x 9" (10 cm x 23 cm)
 4" X 14" (10 cm x 35 cm)
 4" X 18" (10 cm x 45 cm)

QP (plastic plate) Series only:
 4" X 16" (10 cm x 40 cm) *
 4" X 24" (10 cm x 60 cm) *
 4" X 30" (10 cm x 75 cm) *

Adapter Height:

QD Series:
 Swivel flat: 2 1/2" (6 cm)
 Swivel extended: 9" (23 cm)

QD and QS Series:
 Swivel flat: 2 1/2" (6 cm)
 Swivel extended: 5 1/2" (14 cm)

Weight:

Stainless Steel Plate: QD & QS Mop Adapters
Polypropylene Plate: QP Mop Adapters
Acetal Plate: QP Mop Adapters

9 in (23 cm) to 18 in (45cm)

1.3 to 1.6 lb (0.6 to 0.8 kg)
 1.0 to 1.2 lb (0.45 to 0.6 kg)
 N/A

24 in (60 cm) to 30 in (75 cm)

N/A
 N/A
 2.0 to 2.5 lb (0.9 to 1.3 kg)



Micronova Manufacturing, Inc.
 3431 W. Lomita Boulevard
 Torrance, CA 90505-5010 USA

Tel: 310/784-6990
 Fax: 310/784-6980

SalesInfo@micronova-mfg.com
 www.micronova-mfg.com